



## USER GUIDE

Revision 01

**Please Read All Instructions Carefully Before Using**

**Please retain the information in this User Guide for  
future reference**



### **WARNING:**

**CHOKING HAZARD** – Small parts.  
Not for Children under 3 years.

### Battery precautions

- Batteries should only be fitted by adults
- Only batteries of the same or equivalent type as recommended are to be used
- Do not mix non-rechargeable and rechargeable batteries
- Replace batteries when function becomes impaired
- Remove exhausted batteries from your Make'n'Go
- Batteries are to be inserted with correct polarity
- Do not short-circuit the battery terminals
- Always dispose of old batteries safely
- Rechargeable batteries are to be removed from your Make'n'Go before charging

### Getting Started

Locate the aerial inside the connection and screw carefully into the top of the handset

Insert 2 type AA batteries into the handset and type AA batteries into the Make'n'Go. Ensure they are connected correctly as shown on the cover. Discard any exhausted batteries safely.

### Selecting a Channel

1. Make'n'Go can work with three selectable channels
2. Select the same channel on the handset and the Make'n'Go
3. Up to three Make'n'Gos can be used at the same time by using the different channels

### Replaying a sequence

1. Move the left stick on the handset forwards and backwards to make the Make'n'Go travel forwards and backwards
2. Move the right stick on the handset left and right to make the Make'n'Go turn left or right

## Make'n'Go User Guide

---

3. The number of trailers that can be pulled will depend on how much power is left in the batteries
4. The range of the remote control will depend on the battery power

### Technical specification

- Radio frequency 27MHz
- Three separate channels: A, B and C
- Length: 20cm excluding towhook
- Width: 10cm
- Batteries: 3 x AA in Make'n'Go  
2 x AA in Handset

### Support & Warranty

This product is provided with a one-year warranty for problems found during normal usage. Mistreating the Make'n'Go or opening the unit will invalidate this warranty.

All out of warranty repairs will be subject to a replacement fee.

TTS Group Ltd

Freephone: 0800 318686

## Make'n'Go User Guide

---

Unit 1  
Park Lane Business Park  
Kirkby-in-Ashfield  
Nottinghamshire, UK  
NG17 9LE

Freefax: 0800 137525

