



6 Rainbow Mobile Phones with Docking Station

USER GUIDE

Mini-Mobile Phones is a must have communication device for every role play area and children will delight in developing their language using this set of 6 realistic mobile phones. The colour co-ordinated buttons make for easy dialling and three pairs of children can use the phones at once without the need to select different channels.

With a range of up to 50m these phones are ideal for play outdoors as well as use inside. The realistic pre-record and call waiting features also bring them to life.

Best of all these phones are rechargeable using the docking station provided. Just plug them in after use so they are charged up ready for next time.

Contents

Important Information	3
Know Your Mini-Mobile Phones	3
Mini-Mobile Phones Features	4
How to Use Your Mini-Mobile Phones	4
Recharging the Phones	6
Technical Specification	7
Troubleshooting.....	7
Warranty & Support	8

Important Information


Please retain this user guide for future reference and read all the instructions carefully.

- Do not insert any sharp or pointed items into the microphone inlet or speaker outlet. This may cause damage to the microphone or speaker and will void the warranty.
- Do not allow your Mini-Mobile Phones to come into contact with any liquids.

Care Instructions

- To clean the Mini-Mobile Phones wipe gently with a clean damp cloth.

Know Your Mini-Mobile Phones



Mini-Mobile Phones Features

- Full duplex - both callers can talk freely with no need to press a button to talk once a call is in progress.
- Range - 50m outdoors (may be less when used indoors) .
- Call waiting - if you are in the middle of a call, and another phone calls you, you have the option to accept the waiting call, or cancel it.
- Use 3 pairs of phones all at once without needing to select different channels for the phones to work on.
- Colour co-ordinated buttons for easy dialling. Simply press the colour square that corresponds with the colour mobile phone you wish to call.
- Rainbow set - 6 colours to make classroom management easy.
- Record a 10 second message - a message can be recorded and played back for making a note whilst on a call.
- Rechargeable - simply plug your Mini-Mobile Phones into the docking station after use to ensure they are fully charged and ready to use.

How to Use Your Mini-Mobile Phones

The mobile phones are powered by an internal, rechargeable Lithium battery. It is recommended that you should charge the mobile phones for 4 hours before use. To conserve the battery during shipping and storage there is an on/off switch located next to the charging socket. During normal use the switch should be left in the "On" position.

It is however recommended that the phones receive a full charge and are switched to the "Off" position if the phones will not be charged for long periods of time. Failure to do this may result in decreased battery life.



Making a call

To switch the phone on, press and hold the On/Off/End Call button until you hear a chime. The phone is now ready for use. Each mobile phone can call any of the five other phones. Each phone is colour coded. To call a phone, simply press the required coloured key. The phone will ring and the LED will flash. When the call is accepted, the red LED will light to show that you are connected. To end a call at any time, press the button again, or press the end call button briefly.

If the call is not accepted, it will disconnect automatically after 15 seconds.

Message Recording & Playback

The mobile phones can also record and play back up to ten seconds of audio. To record a message, press and hold the record button whilst speaking into the microphone. Simply press the play button to play back the recorded message.

Each subsequent recording will record over the previous message.

Power Saving

To preserve the battery the phone will disconnect a call automatically 10 minutes after the last button press.

Mini-Mobile Phones Status LED

The status LED provides you with a clear indication of the mobile phone battery status:

- Constant Green (when docked) – battery is charged and the phone is ready for use.
- Flashing green - phone is ready for use.
- Flashing red - battery is nearly depleted. Plug the phone into the docking station to recharge.
- Constant Red (when docked) – the phone is charging.

Recharging the Phones

The phones are recharged by inserting them into the Docking Station and plugging the Docking Station into the mains, using the mains power adapter included.

All 6 phones may be charged at the same time in the Docking Station.



International Charger

The Docking Station is supplied with a multi-region adaptor. The adaptor is supplied with the UK plug fitted but you can change this easily to suit any country.

Press the release button and slide the UK plug out and replace it with the required plug module. Slide the plug module in until it "clicks" in place securely.

The safety isolating transformer to be used with the Docking Station should be regularly examined for potential hazards such as damage to the cable, cord, plug, enclosure or other parts. In the event of any damage, the Docking Station must not be used until the damage has been properly repaired.



- The Docking Station is not intended for children under 3 years old.
- The transformer is not a toy.
- The Docking Station must only be used with the recommended transformer.

Technical Specification

Feature	Specification
Transmission Frequency	2.4GHz
Range	50m (outdoor typical)
Battery	3.7V - 300mAh Li-Polymer
External Power Supply	DC 5V
Recording Time	10 seconds
Battery Life	Talk Time - 5 hours Standby - 30 hours (typical)
Battery Charge Time	3 hours

Question	Answer
I cannot receive or make a call from my phone.	Ensure the phone is switched on. Ensure you and the phone you want to connect to are in range. The battery is discharged. Recharge the battery.
I have ended my call, but the phone is indicating the call is still connected.	Reset your phone - slide the ON/OFF switch from On to Off, wait 10 seconds and then resume normal use
Audio quality is poor.	The mobile phones are out of range. Move closer to improve the signal quality. Recharge the battery.

Warranty & Support

This product is provided with a one year warranty for problems found during normal usage. Mistreating the Mini-Mobile Phones or opening the case will invalidate this warranty.

Technical Support

Please visit www.tts-group.co.uk for the latest product information.

Email feedback@tts-group.co.uk for technical support.

TTS Group Ltd.
Park Lane Business Park
Kirkby-in-Ashfield
Nottinghamshire,
NG17 9GU, UK.
Freephone: 0800 318686 Freefax: 0800 137525



WARNING: Do not dispose of this product in household waste. Hand it over to a collection point for recycling electronic appliances.

WARNING! Not suitable for children under 36 months due to small parts – choking hazard.
Made in China, on behalf of the TTS Group Ltd.



TTS is part of the RM group

TTS Group Ltd.,
Park Lane Business Park,
Kirkby-in-Ashfield,
Nottinghamshire, NG17
9GU, UK

TTS Product Code:
EY04195



Visit us today!
www.PRIMARYICT.co.uk
Telephone: 01227 769400