





- ✓ Rechargeable
- ✓ Lockable charging case
- ✓ Lanyard
- ✓ Large screen

40 laps memory

**USER GUIDE** 





# **Important Information**

Please read all instructions carefully before using.

- Please retain these instructions for future reference, as they contain important information.
- All cleaning should be carried out by an adult.
- Products liable to be cleaned with liquids are to be disconnected from the transformer before cleaning.
- Ensure the product is switched off before cleaning begins.
- To clean the Ultimate Timers, wipe with a damp cloth.
- Before using the Ultimate Timers for the first time please charge for 16 hours.

# **Safety Information**

- Your Ultimate Timers are supplied with a 3 x 1.2V ZM20H NiMH rechargeable batteries. Use only the specified battery type with the Ultimate Timers.
- · Batteries should be fitted by an adult.
- Use batteries of the same type.
- Do not mix new and old batteries; replace all batteries at the same time.
- Do not mix rechargeable and non-rechargeable batteries.
- Ensure batteries are inserted with the correct polarity.
- Do not allow the supply terminals to be short-circuited.
- Ensure all used batteries are disposed of in the correct manner.
- Do not allow batteries to come into contact with liquids at any time.
- It is recommended that rechargeable batteries receive a full charge before long periods of storage.

## Fitting & Replacing Batteries

- 1. Remove the back cover of the Ultimate Timers with a screwdriver.
- 2. Remove the exhausted batteries, and dispose of responsibly.
- Fit the new battery pack according to the battery labelling inside the battery compartment.
- 4. Replace the battery cover, and tighten screws.



## **Using your Ultimate Timers**

Your Ultimate Timers are a 40 Lap Memory Stopwatch, with the functionality to be able to review the 40 laps saved in the memory.

### **Timing an Event**

Press the start/stop button to begin timing an event. Press the start/stop button a second time to stop timing.

## Recording a lap time to memory

Whilst an event is being timed, pressing the lap/reset button will place the elapsed time into the Ultimate Timer's memory, timing will continue, and the elapsed time will appear in the top right hand corner of the display.

During timing the lap/reset button can be pressed up to 40 times, allowing 40 different times to be recorded to the Ultimate Timer's memory.

### Reviewing a lap in memory

Laps saved to memory can be viewed at any point, either during timing or when timing has stopped.

Press the 'up' or 'down' buttons to cycle through the saved laps.

## Resetting

With timing stopped, pressing the lap/reset button will reset the stopwatch only. The Lap times will be unaffected.

To reset the lap times in memory press and hold the 'Clear' button using a paperclip.

#### **Low Power Mode**

In low power mode the LCD screen is turned off to extend the life of the battery. Pressing any button will wake up the Ultimate Timer and all stored lap times will be retained.

The Ultimate Timer will enter low power mode if it is left in the stop mode for more than 10 minutes or left timing for more than 24 hours. The Ultimate Timer will also enter low power mode if it is placed in the docking station without the external charger connected.

### **Ultimate Timers Additional Features**

The Ultimate Timers are supplied in a carry case, to make transportation and storage easier. The carry case is also used to recharge the Ultimate Timers. It is recommended that they're left on charge when not in use. The carry case can also be wall mounted and can be padlocked for security.



## **International Charging Adaptor**

The Ultimate Timers are supplied with a multi-region adaptor. The adaptor is supplied with the UK plug fitted but you can change this easily to suit any country. Press the release button behind the plug head and slide the UK plug out and replace with the required plug module. Slide the plug module in until it "clicks" in place securely.

The transformer to be used with the product should be regularly examined for potential hazards such as damage to the cable, cord, plug, enclosure or other parts. In the event of any damage, the adaptor must not be used until the damage has been properly repaired.

The product is not intended for children under 3 years old. The transformer is not a toy.

The product must only be used with the recommended transformer.

# **Technical Specification**

Feature	Specification
Battery Type	3 x 1.2V ZM20H NiMH
Battery Life (Timing mode)	30 hours
Power Supply	International charging adaptor output 7.5V 200mA UK, EU, US, CN, AU 100- 240V 50/60 Hz centre pin positive
Recharge Time	15 hours

# **Troubleshooting**

Question	Answer
My Ultimate Timers will not turn on.	Batteries are flat, recharge using the docking station provided.
The Ultimate Timers will not charge.	Ensure the docking station is powered (When powered the red LED will be on).
The Display is blank.	The Ultimate Timer has entered low power mode. Press any of the buttons to wake it again.

# **Warranty & Support**

This product is provided with a one year manufacturer's warranty. Mistreating the Ultimate Timers or opening the plastics module for reasons other than to replace the batteries will invalidate this warranty.

Made in China, on behalf of the TTS Group LTD.

# **Technical Support**

Please visit www.tts-group.co.uk for the latest product information.


Email: feedback@tts-group.co.uk for technical support.

TTS Group Ltd., Park Lane Business Park, Kirkby-in-Ashfield, Nottinghamshire, NG17 9GU, UK.

Freephone: 0800 318686 Freefax: 0800 137525



WARNING: Do not dispose of this product in household waste. Hand it over to a collection point for recycling electronic appliances.



WARNING! Not suitable for children under 36 months due to small parts – choking hazard.







TTS Group Ltd., Park Lane Business Park, Kirkby-in-Ashfield, Nottinghamshire, NG17 9GU, UK



0800 318 686

www.tts-shopping.com