



## Quick Start Guide

TTS is proud to be part of **RM** plc



TTS Group Ltd., Park Lane Business Park,  
Kirkby-in-Ashfield, Nottinghamshire, UK NG17 9GU

[www.ttsgroupsupport.com](http://www.ttsgroupsupport.com)

### Important Information

Please retain the information in this User Guide for future reference.  
 Please read all instructions fully before using.  
 To clean, wipe the product with a clean damp cloth.  
 Do not allow the product to come into contact with water or other liquids.  
 Keep the product away from direct sunlight and heat.  
 If your product malfunctions please switch it off and then back on again to reset it.  
 Batteries are to be inserted with the correct polarity.  
 The supply terminals are not to be short-circuited.  
 Only batteries of equal size and type should be used.

### Know Your Stopwatch



### Using Your Stopwatch

#### Sleep Mode

When the stopwatch is not in use they will automatically enter sleep mode to conserve the batteries. Press any button to resume operation. Stopwatch will enter sleep mode after 5 minutes of inactivity.

#### Changing the Display Mode

The display has been configured can be configured to show time in 3 different modes:



To change the display mode, use a paper clip to toggle the concealed mode button next to the start/stop button (see Know Your Stopwatch). Each time the button is pressed the display will change mode.

### Changing The Batteries

The stopwatch requires 1 x CR2032 lithium battery (supplied). Undo the screw to release the battery hatch using a small screwdriver. Carefully slide the battery hatch out and lift the exhausted battery from the battery housing. Insert the new battery carefully, making sure it is fitted with the correct polarity. Re-fit the battery hatch and re-tighten the screw.

### Specification

Battery type	1 x CR 2032 Coin Cell
--------------	-----------------------