





Please Read All Instructions Carefully Before Using

CHOKING HAZARD – Small parts. Not for Children under 3 years.

User Guide

Version 2

- Please retain the packaging and these instructions as they contain important information
- Do not allow your Easi-Speak Docking Station to come into contact with water or other liquids
- Warranty is void if the case is opened for any reason
- The warranty does not cover any data loss from the unit nor any consequential loss of information

FCC compliance

NOTE:

THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER AUTHORITY TO OPERATE THE EQUIPMENT

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.


2

Easi-Speak docking station User Guide

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Know your Easi-Speak docking station



Using your Easi-Speak docking station



Place the Easi-Speak or Easi-Speak Pro in the docking station with the status LED facing outwards.



The Easi-Speak docking station is supplied with a multi-region adaptor. The adaptor is supplied with the UK plug fitted but you can change this easily to suit any country. Press the release button and slide the UK plug out and replace with the required plug module. Slide the plug module in until it "clicks" in place securely

The safety isolating transformer to be used with the Docking Station should be regularly examined for potential hazards such as damage to the cable, cord, plug, enclosure or other parts. In the event of any damage, the Docking Station must not be used until any damage has been properly repaired.

- The Docking Station is not intended for children under 3 years old
- The transformer is not a toy

4

 The Docking Station must only be used with the recommended transformer

Troubleshooting

The easi-Speak docking station is designed to work reliably and predictably in all normal conditions. However, it is possible that problems may occur. Please check the following before contacting technical support:

Problem	Power LED does not light	
Solution	Check that the mains adaptor is connected and the mains outlet is witched on	
Problem	Cannot fit the Easi-Speak into the socket	
Solution	Make sure that the status LED on the Easi- Speak faces outwards	
Problem	The Easi-Speaks do not charge	
Solution	Ensure that the power LED is on and that all Easi-Speaks are switched off whilst charging	

Power supply specification

Input Voltage	100 – 240V a.c.
Frequency	50 – 60 Hz
Standby power	0.3W (Max)
Output Voltage	5V d.c. ± 5%
Output Current	1500mA (Max)

Easi-Speak docking station user Guide

Output power 7.5W

Support & Warranty

This product is provided with a one-year warranty for problems found during normal usage. Mistreating the Easi-Speak docking stationTM or opening the unit will invalidate this warranty. All out of warranty repairs will be subject to a replacement fee.

Please visit www.tts-group.co.uk for latest product information.

Email feedback@tts-group.co.uk for technical support.

TTS Group Ltd Park Lane Business Park Kirkby-in-Ashfield Nottinghamshire, NG17 9GU Freefax: 0800 318686 Freefax: 0800 137525



